

## Vancouver Scissor Lift Certification

Vancouver Scissor Lift Certification - Many worksites and tradespeople like masons, iron workers and welders make use of scissor lift platforms to help them reach elevated work places. The operation of a scissor lift is often secondary to their trade. Hence, it is important that all platform operators be trained well and certified. Lift manufacturers, regulators and industry work together to make certain that operators are trained in the safe utilization of work platforms.

Scissor lift work platforms are otherwise called manlifts or AWP's. These work machines are quite easy to use and provide a steady work setting, then again they do have dangers since they raise individuals. The following are several key safety issues common to AWP's:

There is a minimum safe approach distance (likewise known as MSAD) for all platforms so as to protect from accidental discharge of power because of proximity to power lines and wires. Voltage can arc across the air and cause injury to workers on a work platform if MSAD is not observed.

Care should be taken when lowering a work platform to ensure stability. The boom should be retracted, moving the load toward the turntable. This would help maintain steadiness in lowering of the platform.

The rules regarding tie offs do not mandate those working on a scissor lift to tie themselves off. Several organizations will on the other hand, require their workers to tie off in their employer guidelines, job-specific risk assessments or local regulations. The anchorage provided by the manufacturer is the only safe anchorage wherein lanyard and harness combinations must be connected.

Observe the maximum slope rating and do not go beyond it. A grade could be measured by laying a straight edge or board on the slope. A carpenter's level can then be placed on the straight edge and raised until the end is level. By measuring the distance to the ground and dividing the rise by the length of the straight edge, then multiplying by 100, you could determine the percent slope.

In order to determine whether the unit is mechanically safe, a standard walk-around inspection must be performed. Work site assessments are also essential to make sure that the work area is safe. This is essential especially on changing construction sites because of the risk of obstacles, contact with power lines and unimproved surfaces. A function test has to be done. If the unit is operated safely and properly and right shutdown measures are followed, the possibilities of accidents are really lessened.